



**NOKTON 40mm F1.2 Aspherical II
VM-mount**

INSTRUCTION MANUAL

Voigtländer VM-mount lenses cover the full frame format and are manually controlled lenses. The user sets focus and aperture. They are designed to be used on both rangefinder film cameras and digital cameras with M-type lens mount. They can also be used on mirrorless cameras with appropriate adapters.

Features of Voigtländer VM-mount lens

- VM-mount
- Full frame format
- Smooth focus for precise focusing
- All metal construction

Tips for lens care and safety

These tips are to protect the user from injury or damaging the lens.



WARNING

If the user ignores this warning sign and uses the equipment the wrong way serious injuries and even death might be the result.



CAUTION

If the user ignores this caution sign it might result in injuries and damage the equipment.



WARNING

Never look directly at the sun with a telephoto lens as this can damage your eyes.



CAUTION

Keep the lens, camera and accessories out of reach of children.



CAUTION

Store the lens away from direct sunlight and always store the lens with lens-cap on. Failure to do so can create a fire hazard.

Never touch the lens surface. In case it is dirty or dusty use commercial lens cleaner or appropriate lens cleaning cloth.

● How to attach/detach the lens

Please refer to the instruction manual for your camera for how to attach/detach the lens. Please hold Depth of Field Ring ⑤ to attach/detach the lens. To attach/detach the lens while holding other parts of the lens barrel can damage the lens.

● Rangefinder coupling

Coupled focusing range of this lens is $\infty \sim 0.7\text{m}$. However, rangefinder coupling range will be different depending on the rangefinder mechanism of the camera used.

● Attaching Filter

Screw the filter ($\varnothing 52\text{mm}$) to the front of the lens.

● Attaching Mount Adapter

This lens can be used with below mentioned Voigtländer accessories.

VM-E Mount Adapter II

VM-E Close Focus Adapter II

VM-X Close Focus Adapter II

VM-Z Close Focus Adapter

● Optional Lens Hoods LH-14 or LH-15

Please ask your dealer for details.

● Attachment and Removal of optional Lens Hood

To attach, align the white dot on the lens hood with the aperture indicator ⊗ and turn the lens hood clockwise until it stops. To remove the lens hood, turn the lens hood counterclockwise.



● Specifications

| | |
|----------------------|--------------------------------|
| Product Name | NOKTON 40mm F1.2 Aspherical II |
| Focal Length | 40mm |
| Maximum Aperture | F1.2 |
| Minimum Aperture | F22 |
| Lens Construction | 6 groups 8 elements |
| Angle of View | 54.7° |
| Aperture Blade | 10 |
| Rangefinder Coupling | ∞ ~ 0.7m |
| Minimum Focus | 0.5m |
| Filter | Ø52mm |
| Maximum Diameter | Approx. Ø61.8mm |
| Length | Approx. 44.7mm |
| Weight | Approx. 300g |
| Mount | VM-mount |
| Supplied Accessory | Front Cap, Rear Cap |

* Specification and information is subject to change without prior notice.