

NOKTON Vintage Line 50mm F1.5 Aspherical II VM

INSTRUCTION MANUAL

Voigtländer VM-mount lenses cover full frame format and are manually controlled lenses. The user sets the focus and aperture. They are designed to be used on both rangefinder film cameras and digital cameras with M-type lens mount. They can also be used on mirrorless cameras with the appropriate adapters.

Features of Voigtländer VM-mount lens

- VM-mount
- Full frame format
- Smooth focus for precise focusing
- All metal construction

Tips for lens care and safety

These tips are to protect the user from injury or damaging the lens.

Ŵ	WARNING	If the user ignores this warning sign and uses the equipment the wrong way serious injuries and even death might be the result.
---	---------	---

\triangle	CAUTION	If the user ignores this caution sign it might result in injuries and damage the equipment.
-------------	---------	---

WARNING	Never look directly at the sun with a telephoto lens as it may this can damage your eyes.
---------	---


! CAUTION	Keep the ler	s, camera and	daccessories	out of reach of
------------------	--------------	---------------	--------------	-----------------

\triangle	CAUTION	Store the lens away from direct sunlight and always store the lens with lens-cap on. Failure to do so may create a fire hazard.
-------------	---------	---

Never touch the lens surface. In case it is dirty or dusty use commercial lens cleaner or appropriate lens cleaning cloth.

Description of Parts

- ① Filter Ring
- ② Aperture Ring
- 3 Focus Ring
- ④ Distance Scale
- ⑤ Depth of Field Ring
- ⑥ Distance Index
- Mount
- Aperture Index
- Aperture Scale
- 10 Depth of Field Scale
- ① Mount Index



How to attach/detach the lens

Please refer to the instruction manual for your camera for how to attach/detach the lens. Please hold the Depth of Field Ring ③ to attach/detach the lens. To attach/detach the lens while holding other parts of the lens barrel can damage the lens.

Rangefinder coupling

Coupled focusing range of this lens is $\infty \sim 0.7$ m. However, rangefinder coupling range will be different depending on the rangefinder mechanism of the camera used.

Attaching Filter

Screw the filter (Ø43mm) to the front of the lens.

Attaching Mount Adapter

This lens can be used with below mentioned Voigtländer accessories.
VM-E Mount Adapter II
VM-E Close Focus Adapter
VM-X Close Focus Adapter
VM-Z Close Focus Adapter

Optional Lens Hood LH-6

Optional Lens Hood LH-6 are available to be purchased separately. Please ask your dealer for details.

● Attachment and Removal of optional Lens Hood
To attach, line-up the white mark on the Lens Hood
with Aperture Index ⑨ on the Iens and turn the Lens
Hood clockwise while pushing it toward the Iens.
To remove, push the Lens Hood toward the Iens and
turn it counterclockwise



Specifications

Product Name	NOKTON Vintage Line 50mm F1.5 Aspherical II
Focal Length	50mm
Maximum Aperture	F1.5
Minimum Aperture	F16
Lens Construction	7 groups 8 elements
Angle of View	46.3°
Aperture Blade	12
Rangefinder Coupling	∞ ~ 0.7m
Minimum Focus	0.7m
Filter	Ø43mm
Maximum Diameter	Approx. Ø55.3mm
Length	Approx. 36.9mm
Weight	Black / Silver Approx. 198g Nickel • Black paint Approx. 225g
Mount	VM-mount
Supplied Accessory	Front Cap, Rear Cap

^{*} Specification and information is subject to change without prior notice.