

NOKTON Vintage Line 35mm F1.5 Aspherical Type I / II VM

INSTRUCTION MANUAL

Voigtländer VM-mount lenses cover the full frame format and are manually controlled lenses. The user manually sets the focus and aperture. They are designed to be used on both rangefinder film cameras and digital cameras with M-type lens mount. They can also be used on mirrorless cameras with appropriate adapters.

Features of Voigtländer VM-mount lens

- VM-mount
- Full frame format
- Smooth focus for precise focusing
- Full metallic construction

Tips for lens care and safety

These tips are to protect the user from injury or damaging the lens.

children


\triangle	WARNING	the user ignores this warning sign and uses the equipment the wrong way serious injuries and even death might be the result.
\triangle	CAUTION	If the user ignores this caution sign it might result in injuries and damage the equipment.
\triangle	WARNING	Never look directly at the sun with a telephoto lens as it may this can damage your eyes.
\wedge	CALITION	Keep the lens, camera and accessories out of reach of

Store the lens away from direct sunlight and always store the lens with lens-cap on. Failure to do so may create a fire hazard.

Never touch the lens surface. If it is dirty or dusty, use commercial lens cleaner or an appropriate lens cleaning cloth.

Description of Parts

- Filter Ring
- ② Aperture Ring
- ③ Focusing Ring
- ④ Distance Scale
- ⑤ Depth of Field Ring
- ⑥ Distance Index
- ⑦ Mount
- Aperture Index
- Aperture Scale
- 10 Depth of Field Scale
- Mount Index



How to attach/detach the lens

Please refer to the instruction manual for your camera for how to attach/detach the lens. Please be sure to hold the Depth of Field Ring ③ when attaching/detaching the lens. To attach/detach the lens while holding other parts of the lens barrel may damage the lens.

Rangefinder coupling

Coupled focusing range of this lens is $\infty \sim 0.7$ m. However, the rangefinder coupling range will be different depending on the rangefinder mechanism of the camera used

Attaching Filter

Screw the filter (Ø39mm) to the front of the lens.

Attaching Mount Adapter

This lens can be used with below mentioned Voigtländer accessories.

VM-E Mount Adapter II

VM-E Close Focus Adapter

VM-X Close Focus Adapter

VM-Z Close Focus Adapter

Optional Lens Hood LH-4N, LH-12

Optional Lens Hoods LH-4N and LH-12 are available. Please ask your dealer for details.

Attachment and Removal of optional Lens Hood

To attach, line-up the white mark on the Lens Hood with Aperture Index ® on the lens and turn the Lens Hood clockwise while pushing it toward the lens. To remove it, push down on the Lens Hood toward the lens and turn it counterclockwise.



Specifications

Product Name	NOKTON Vintage Line 35mm F1.5 Aspherical
Focal Length	35mm
Maximum Aperture	F1.5
Minimum Aperture	F16
Lens Construction	6 groups 9 elements
Angle of View	61.7°
Aperture Blade	12
Rangefinder Coupling	∞ ~ 0.7m
Minimum Focus	0.5m
Filter	Ø39mm
Maximum Diameter	Ø53.0mm
Length	Approx. 36.0mm
Weight	Type I: Approx. 188g Type I: Approx. 284g
Mount	VM-mount
Supplied Accessory	Front Cap, Rear Cap

^{*} Specification and information is subject to change without prior notice.